


Die Module sind in dafür bestimmte Halterahmen einzusetzen, die sowohl in die Standardgehäuse als auch in die Komponenten des COB-Systems montiert werden können.

Rahmen für Modulareinsätze.. Seite 151

**Blindmodul**




Beschreibung

Artikel-  
bezeichnung

Blindmodul für nicht benutzte Modulplätze

**CX FM**

Abmessungen in mm



Ansicht von der Kontaktseite

Referenzpfeil für Modulpolarität ▲



- Platzbedarf 1 Modulbreite


Die angegebenen Abmessungen sind nicht verbindlich.  
Technische Änderungen sind vorbehalten.

MIXO

the modular units inserts must be installed in suitable frames which in turn are installed in traditional housings or COB panel support. Alternatively, individual modules with a width of 14.7, can be installed in plastic supports.

frames for modular units ..... page: 151

dummy module




description

part No.

dummy module for unused frame seats

**CX FM**

dimensions in mm



position of units (coupling side view)

side with reference arrow ▲



- footprint 1 module

dimensions shown are not binding and may be changed without notice